


FLOW-BUS

Hook-up diagram

FLOW-BUS connection



Types

D-6300 Series


Model key explanation

D - **NNNN** - **XXX** - **XX** - **XX** - **NN** - **X** - **S** - **DX**


- A** Output / setpoint 0...5Vdc
- B** Output / setpoint 0...10Vdc
- F** Output 0...20mAdc sourcing
Setpoint 0...20mAdc sinking
- G** Output 4...20mAdc sourcing
Setpoint 4...20mAdc sinking
- D** +15Vdc ... 24Vdc power supply

F FLOW-BUS

M12 connector male chassis part A-coded



8 DIN connector chassis part male



Note:
When using a field bus or RS232, it is not possible to operate the instrument by using the setpoint signal of the analog 8 DIN connector without changing the value of parameter "control mode".
See doc.no. 9.17.023 for more details

Note:
Do not connect an external valve to instruments, set as MFM.

Note:
Powering a single instrument is possible by the 8 DIN connector.
See doc.no. 9.16.092 for the hook-up diagram.